

CHOOSING THE IDEAL COOLING PACK BASED VEST OR ACCESSORY



1 WHICH REUSABLE COOLING TECHNOLOGY SHOULD YOU CHOOSE?



KOOL MAX®

Cooling vests with Kool Max® frozen water-based cooling packs fit into insulated pockets. Packs require access to a freezer and 2 to 3 hours to charge. They offer the highest level of cooling energy. *It's science! It takes more energy to charge these packs in a freezer and in return, the packs offer greater cooling energy for a longer time.* Vests will cool for approximately 3 to 4 hours; accessories will cool for 1 to 2 hours.



COOL58®

Cooling vests with Cool 58® phase change cooling packs fit into insulated pockets. Packs freeze at 58°F (14.4°C) and provide a comfortable, constant cooling temperature of 58°F. Ideal choice when freezers are not available; these packs can be recharged in a cooler of ice water in just 15 to 20 minutes or a refrigerator in 1-1.5 hours. Vests will cool for approximately 2 to 3 hours; accessories will cool for 1 to 1.5 hours.



HOME AND AWAY KITS (available only with the small pack configuration.)

Our home and away kits include a vest and one set of each style of pack. Kool Max® for when you have easy access to a freezer; Cool 58® when you are working outdoors or remotely and only have access to a cooler of ice water

2 WHICH STYLE OF VEST WOULD YOU PREFER?

Our POLAR ADJUSTABLE VESTS have adjustable hook and loop straps at the chest, waist and shoulders for a snug, comfortable and customized fit. Size charts are located on the purchase pages. They come with two different pack configurations:



SEGMENTED STRIP PACK CONFIGURATION

Adjustable vests using our segmented Cool58 strip packs include four (4) sectioned strip packs. These vests are available with 5" x 12.5" 400 gram (.88 lbs.) packs (total vest weight 4.0lb) or 6" x 13" 500 gram (1.1 lb) packs (total vest weight 5.5 lb).



4.5" X 6" PACK CONFIGURATION

Adjustable vests using 4.5 X 6" packs include 8 to 12 packs depending on vest size. This configuration allows the user to adjust the number, location and weight of the vest as desired. Sizes range from XS/S to 3XL/4XL and the number of packs increases with size. Each pack weighs 6.4 oz. Back cooling packs are located along the spine for efficient cooling. Adjustable vests with 4.6" x 6" packs are available in khaki, blue, gray and black



3 WHICH FABRIC WOULD YOU PREFER?

Cotton: lightweight and breathable 100% cotton twill

Nylon: 100% two-ply soft, breathable, easy-clean nylon

"This Polar Cool58 vest is the best cooling system I have ever purchased!! I work in a hot warehouse and at each break I change the packs and it keeps me cool. I also have an extra set of four packs that I keep in the thermal cooler with some ice packs and it works for me! I really recommend this cooling vest."

- Lynn in New Jersey



"Bought this Polar Cool58 Industrial Cooling Vest for my husband who works in the oil fields. He calls me daily to tell me how awesome I am because I got this for him. Oklahoma heat with no a/c is brutal so this is a PERFECT solution. The [Cool58®] gel packs are amazing, he just fills the cooler with ice and 20 minutes later they are frozen solid. Less than a dollar a day for ice at a truck stop and he is cool and comfortable."

- E. in Oklahoma



"This is my third year using the Kool Max® Industrial Vest. It provides the cooling relief needed while working in a hot factory"

- Lawrence in Michigan



Contract Holder
Contract V7979D-30220

To see all of our body cooling and therapy products, visit polarproducts.com.

1.800.763.8423 | polar@polarproducts.com

polarproducts.com

